

Table of Contents



vi	Table of Contents	2	Basic Camera Setup
xiii	Foreword	3	D300S and D300 Reference Material
xiv	Camera Body Reference	4	First-Time DSLR Users
xvii	Colors and Wording Legend	5	Shoot Now Camera Configuration
		5	Accessing the Camera Menus
		7	Camera Functions for Initial Configuration
		8	Author's Personal Camera Setting Recommendations
		9	My Conclusions




10 Playback Menu

- 12 Delete (images)
- 15 Playback Folder
- 16 Hide Image
- 18 Display Mode
- 23 Copy Images (D300S)
- 28 Image Review
- 29 After Delete
- 31 Rotate Tall
- 32 Slide Show
- 35 Print Set (DPOF)
- 35 My Conclusions



36 Shooting Menu

- 39 Shooting Menu Bank
- 43 Reset Shooting Menu
- 44 Active Folder
- 45 File Naming
- 48 Primary Slot Selection (D300S)
- 49 Secondary Slot Function (D300S)
- 50 Image Quality
- 60 Image Size
- 61 JPEG Compression
- 63 NEF (RAW) Recording
- 68 White Balance
- 70 Set Picture Control
- 79 Manage Picture Control
- 88 Color Space
- 90 Active D-Lighting
- 92 Long Exp. NR
- 95 High ISO NR
- 97 ISO Sensitivity Settings
- 104 Live View Mode
- 106 Multiple Exposure
- 109 Movie Settings (D300S)
- 111 Interval Timer Shooting
- 115 My Conclusions



116 Custom Setting Menu

- 117 Renaming a Custom Setting Bank
- 119 Reset Custom Settings
- 120 (a) Autofocus – a1 to a10
- 138 (b) Metering/Exposure – b1 to b6
- 149 (c) Timers/AE Lock – c1 to c4
- 155 (d) Shooting/Display – d1 to d12
- 172 (e) Bracketing/Flash – e1 to e7
- 193 (f) Controls – f1 to f11
- 216 My Conclusions

Note: There are over 50 functions discussed in this large chapter. For specific page numbers on each setting please see the *Custom Settings* entry in the Index.



218 Setup Menu

- 221 Format Memory Card
- 224 LCD Brightness
- 225 Clean Image Sensor
- 227 Lock Mirror Up for Cleaning
- 228 Video Mode
- 229 HDMI
- 230 Time Zone and Date or World Time
- 233 Language
- 234 Image Comment
- 236 Image Rotation
- 237 USB (D300)
- 238 Image Dust Off Ref Photo
- 241 Battery Info
- 243 Wireless Transmitter
- 244 Image Authentication
- 245 Copyright Information (D300S)
- 247 Save/Load Settings
- 249 GPS
- 254 Virtual Horizon (D300S)
- 254 Non-CPU Lens Data
- 257 AF Fine Tune
- 260 Eye-Fi Upload (D300S)
- 261 Firmware Version
- 263 My Conclusions



264 Retouch Menu

- 267 Playback Retouching
- 267 Using Retouch Menu Items Directly
- 267 D-Lighting
- 268 Red-Eye Correction
- 269 Trim
- 270 Monochrome
- 271 Filter Effects
- 272 Color Balance
- 273 Image Overlay
- 275 NEF (RAW) Processing (D300S)
- 281 Resize (D300S)
- 283 Edit Movie (D300S)
- 284 Side-By-Side Comparison
- 285 My Conclusions



286 My Menu and Recent Settings

- 287 Two Specialty Menus
- 288 My Menu
- 288 Add Items
- 290 Remove Items
- 290 Rank Items
- 291 Choose Tab
- 292 Recent Settings (D300S)
- 293 My Conclusions
- 293 D300S Sample Image



294 Live View and D-Movie Modes

- 295 Live View Mode
- 296 Live View's Two Modes
- 298 Live View's Four Screens
- 303 D-Movie Mode
- 303 High-Definition (HD) Video
- 304 Progressive vs. Interlaced
- 304 Camera Setup for D-Movies
- 304 Which Video Encoding Method?
- 305 Selecting a Video Quality
- 307 Dealing with Sound on D-Movies
- 308 Choosing a Destination for Video Recordings
- 309 Recording a Video with Your D300S
- 310 Using Picture Controls
- 311 Displaying D-Movies...
 - 311 On the Camera LCD Screen
 - 311 On a Standard Definition TV
 - 313 On a High Definition TV (HDTV)
- 315 Limitations in Video Capture
- 315 How the Rolling Shutter Works
- 317 Avoiding the "Jellywobble Effect"
- 318 My Conclusions
- 319 Video Editing Software

320 Metering, Exposure Modes, and Histogram

- 320 Metering Systems
 - 321 3D Color Matrix II Meter
 - 322 Fine-Tuning Matrix Metering
 - 323 Using Flash with Matrix Metering
 - 323 Center-Weighted Meter
 - 324 Where's the Circle?
 - 324 What about the Averaging Meter?
 - 324 Spot Meter
- 326 Exposure Modes
 - 327 P – Programmed Auto Mode
 - 328 S – Shutter Priority Auto Mode
 - 329 A – Aperture Priority Auto Mode
 - 330 M – Manual Mode
- 331 Histogram
 - 332 Understanding the Histogram
 - 332 Light Range
 - 333 Histogram Shape
 - 335 How Does the Eye React to Light?
 - 336 Computer Adjustment of Images
 - 338 My Conclusions




340 White Balance

- 341 How Does White Balance Work?
- 341 White Balance Fundamentals
- 341 Color Temperature
- 343 Manual White Balance
- 343 White Balance Symbols
- 344 Manual Color Temperature Selection
- 344 Measuring Ambient Light (PRE)
- 345 Storing White Balance Values
- 346 Editing the Comment Field
- 347 Using a Saved White Balance
- 348 Adjusting a Saved White Balance
- 349 Manual White Balance Using the Shooting Menu
- 350 White Balance Bracketing
- 352 Auto White Balance
- 352 Author Opinion on White Balance
- 353 White Balance and RAW Shooting
- 354 White Balance Tips and Tricks
- 354 Sample 2500 K to 10000 K Image
- 355 My Conclusions



356 Multi-CAM 3500 DX Autofocus

- 357 What is the Multi-CAM 3500DX Autofocus Module?
- 358 Using Manual Focus
- 358 Understanding the Focus, AF-Area, and Release Modes
- 360 Single-servo AF Mode (S)
- 360 Continuous-servo AF Mode (C)
- 361 Predictive Focus Tracking
- 361 AF-Area Modes in Detail
- 361 Single-point AF
- 363 Dynamic-area AF
- 365 Auto-area AF
- 365 Release Modes in Detail
- 366 Single Frame (S) Mode
- 366 Continuous Low Speed (CL) Mode
- 366 Continuous High Speed (CH) Mode
- 366 Quiet (Q) Mode (D300S)
- 367 Live View (LV) Mode (D300)
- 367 Self-Timer Mode
- 368 Mirror Up (MUP) Mode
- 369 Autofocus in Live View Mode
- 369 Hand-held or Tripod Modes
- 369 Release Mode Frame Rate
- 371 My Conclusions



372 Speedlight Flash Photography

- 373 Light is the Photographer's Friend
- 373 What is a Guide Number?
- 376 Flash Modes
- 376 What are Monitor Preflashes?
- 378 Front-Curtain Sync
- 378 Red-Eye Reduction
- 378 Red-Eye Reduction with Slow-Sync
- 379 Slow Sync
- 379 Rear-Curtain Sync
- 380 Auto FP High-Speed Sync
- 381 Nikon Creative Lighting System
- 382 What is Commander Mode?
- 383 Using Commander Mode
- 383 Commander Mode Settings
- 385 Selecting a Nikon Speedlight Unit
- 385 SB-900 Speedlight
- 386 SB-800 Speedlight
- 386 SB-600 Speedlight
- 387 SB-R200 Speedlight
- 387 SU-800 Wireless Commander Unit
- 388 My Conclusion
- 389 Author – Thank You!

User's Manual Information

All User's Manual page references mentioned in this book are from specific manual production years. The User's Manual references for the D300 are from the 2008 version and the 2009 version for the D300S. If you have newer User's Manuals there may be minor page variances due to modifications by Nikon.